

100% MADE IN THE USA

PLASTER MAGIC[®]

FOR THE ULTIMATE PLASTER REPAIR[®]

PATCHING PLASTER

SPECIALLY FORMULATED FOR FIXING OLD PLASTER
ON WOOD, WIRE & ROCK LATH

Available in two sizes for filling holes that go all the way to the lath:

PAINTERS PATCHING PLASTER 250 sq. in. Coverage

CONTRACTORS PATCHING PLASTER 500 sq. in. Coverage

PROFESSIONAL-GRADE REPAIRS
EASY TO USE, JUST ADD WATER
CLEAN & GREEN



Find Products, Helpful Videos & Repair Tips at
WWW.PLASTERMAGIC.COM



1 CONDITION IT

For the longest lasting repair, some preparatory work needs to be done.

- Clean out any loose plaster that you can see between the lath and around the perimeter of the hole.
- Stabilize the existing plaster using a Plaster Magic repair kit by gluing the loose plaster to every strip of lath around the perimeter of the hole, or every 2" around the hole for wire lath.
- After the adhesive has been applied and the plastic clamps are in place, spray the wood lath and raw edges of the existing plaster again with Plaster Magic conditioner three times (let it soak in before you spray the area again).
- Allow the stabilized plaster to set up overnight.

YOU CAN DO THIS®

Hint: The more irregular the hole is, the easier it is to hide; the better the mechanical bond (i.e. due to the rough edges of the existing plaster), the harder it is to see after the repair.



2 MIX IT

FOR YOUR SAFETY, PLEASE WEAR OSHA-APPROVED DUST MASK & EYE PROTECTION

Once the perimeter of the hole has been stabilized, mix up the Plaster Magic patching plaster. The goal is to make enough mix to fill the hole halfway for two layers or — if the hole is smaller than your hand — fill in one layer.

- Pour some of the dry mix into the plastic mixing container.
- Add a small amount of water, stirring into the patching plaster to create a peanut butter-like paste (it's much easier to add extra water than it is to take it out).



3 PATCH IT

- Tuck the patching plaster under the edges of the existing plaster and into the key ways (the spaces between the lath).
- Scratch the surface of this first layer of patching plaster to provide texture for the next layer of patching plaster to bond to.
- Let the first batch of plaster set up, approximately 1–2 hours.
- Mix and apply the second layer of plaster to fill the hole.



4 FINISH IT

- Remove any dried patching plaster left on the surface of the existing plaster with the putty knife.
- Apply a topping of joint compound to fill in any cosmetic defects.
- Let dry and lightly sand.

**THAT'S IT, YOU'RE GOOD TO GO!
PAINT, PAPER, FINISH AS DESIRED**

TO CLEAN UP: Use warm, soapy water to wash utensils. DO NOT empty any patching plaster into sink. Store dry mix in a sealed plastic bag in a cool, dry place.

PATCHING PLASTER • SIMPLE TOOLS NEEDED



Margin Trowel



Midget Trowel



Sponge & Bucket of Water



Safety Glasses



Putty Knives

CAUTION

- Avoid contact with skin and eyes. If contact with eyes, wash eyes repeatedly for 15 minutes and call physician immediately.
- Do not take internally; if ingested, do not induce vomiting; call a physician immediately.
- When mixed with water, this material hardens and then slowly becomes hot. Failure to follow these instructions may cause burns.
- May dry skin.
- Breathing of dust may cause irritation to the eyes, nose, throat or upper respiratory system.
- Keep out of reach of children.

PLASTER MAGIC®

FOR THE ULTIMATE PLASTER REPAIR™

NEED HELP? VISIT
WWW.PLASTERMAGIC.COM

Patching Plaster Protected by Patent Number US: 9,333,877 B2
© 2014 EWA, Inc. All Rights Reserved.